

Instructies

1. Select effect

(1) Normal mode. Turn on the pedal and press the SAVE button to switch between each effect.

(2) Preset rolling mode. Turn the pedal on and press TAP and BYPASS simultaneously to enter preset switching mode which will be indicated by the footswitch LED and SAVE button blinking in red. In this mode, users can roll down/up through each effect by using the TAP and BYPASS footswitches. The pedal will exit rolling mode if the pedal is idle for 3 seconds.

2. Preset saving

The LED indicator will blink slowly when any parameter has been changed. Users can press and hold the SAVE button to store changes. The LED indicator will blink quickly for a short duration to confirm saving. Alternatively, users can quickly press the SAVE button again to cancel those changes.

3. TAP TEMPO

Turn on the pedal and press the TAP footswitch several times to set up a tap tempo speed. The TAP LED indicator will show current speed by blinking.

4. Trail On/Off

After turning on the pedal, press and hold the BYPASS footswitch for 2 seconds. The BYPASS indicator will blink and change color to confirm. The blue LED indicates trail mode is on while Red indicates trail mode is off.

5. Factory reset

Unplug the power cord then press and hold the SAVE button while powering on the pedal again. The 7 LEDs will start to blink slowly. Release the SAVE button and the LED indicator will blink quickly to confirm a successful factory reset. You can unplug the power cord before releasing the SAVE button to cancel the factory reset.

*** Factory reset will clear all presets stored by user.**

Tweak Parameter and Effect List

Slot	LED color	Effect Name	TWEAK.1	TWEAK.2	Description
1	Yellow	DIGITAL	LOW-CUT	HIGH-CUT	Clean digital delay. Adjust brightness with tweak knobs.
2	Yellow	ANALOG	LOW-CUT	HIGH-CUT	A warm and soft analog style digital delay.
3	Yellow	TAPE	FILTER	VIBRATO(MIX)	Vintage echo delay. Tweak can turn the delay from tape player to vinyl record player.
4	Yellow	DYNAMIC	THRESHOLD	tone	Change the delay type according to the input signal.
5	Yellow	LIQUID	STEP-PHASER (RATE)	STEP-PHASER (MIX)	Modulated delay effect with step phaser with a flowing liquid-like tone.
6	Yellow	MOD	MOD RATE	MOD DEPTH	Splendid modulation delay effect with wide area and depth.
7	Yellow	MOD-VERSE	FLANGER (RATE)	FLANGER (MIX)	Delay met omgekeerd afspeleffect.
1	Purple	GALAXY	POST-SLOW GEAR	CHORUS(MIX)	Post-slow gear features a smooth and gradual feedback sound, creating a wide sense of space and atmosphere.
2	Purple	DUAL	WIDTH	TIME 2	Dual-delay effect. Delay timing can be set individually. Adjust WIDTH to control the mix rate of the two delays.
3	Purple	PINGPONG	LOW-CUT	HIGH-CUT	Signal alternates from left to right outputs, enhancing the stereo output feel.
4	Purple	CRYSTAL	MOD-DEPTH	MOD-RATE	Delay with upperoctave pitch effect and crystal-like tone.
5	Purple	RAINBOW	STUTTER	PITCH DEGREE	Pitch effect with stutter-speed fluctuation and fantastic delay tone.
6	Purple	LOW-BIT	PRE-SLOW GEAR	LOWBIT	Tweakable from tiny low-bit effect to white noise effect. Suitable for experimental music.
7	Purple	FUZZ	FUZZ GAIN	FUZZ TONE	Fuzz effect added into the feedback sound of delay, creating an area with noise and chaos.

Specifications

Input: 2*1/4" mono audio input jack (Impedance value 1Mohms)
Output: 2*1/4" mono audio output jack (Impedance value 510ohms)
Power requirement: 9V power supply (center negative)
Current draw: 300MA (Center negative).
 Recommended to use only the original power supply included with the pedal. Using third-party power supplies may cause noise or other unexpected issues.

Dimension: 5x115x33mm
Weight: 0.334kg
Accessories: power supply, quick guide, sticker

MOOER
www.moeraudio.com



203050179301

SHENZHEN MOOER AUDIO CO. LTD
 6F, Unit D, Jinghang Building, Lixian 3rd Road,
 Bao'an 71 District, Shenzhen, China. 518133
 Made in China